

**Important: Retain these instructions**

These instructions shall be used by trained service personnel only. If the equipment is used in a manner not specified by these instructions, the protection provided by the equipment may be impaired.


<https://partners.trendcontrols.com>



### CONTENTS


1	Box contents.....	1	3	Installation.....	1
2	Storing.....	1	4	Disposal.....	2

### 1 BOX CONTENTS



XCITE/BBC Installation Instructions (TG200686)

### 2 STORING



### 3 INSTALLATION

**1 Switch off**

**2 Isolate I/O**

also isolate any I/O modules

**WARNING:** The connecting leads may be connected to supplies. Isolate before touching.


**3 Open Panel**

**WARNING:** Opening the panel may expose dangerous voltages.  
417-IEC-5036


**4 Remove Auxiliary Board Cover**

3 INSTALLATION (continued)


**5 Plug in Battery Board**  
 apply plate  
 plate supplied with XCITE/BBC




apply board to plate



press board home




**6 Insert Battery**  
 CR2032 3V supplied with XCITE/BBC




**Warning:** The lithium battery must not be recharged, disassembled, burnt or short circuited. Misuse may cause explosion or fire. Dispose of carefully. Refer to Health and Safety Executive Guidance Note GS43 - see section 4, Disposal, below.


**7 Replace Auxillary Board Cover**



**8 Close Panel**




**9 Reconnect Supply to I/O**




also reconnect any I/O modules

**10 Switch On**



4 DISPOSAL



**WEEE Directive:**  
 At the end of their useful life the packaging and product should be disposed of by a suitable recycling centre.  
 Do not dispose of with normal household waste.  
 Do not burn.

Please send any comments about this or any other Trend technical publication to [techpubs@trendcontrols.com](mailto:techpubs@trendcontrols.com)

© 2018 Honeywell Technologies Sàrl, E&ES Division. All rights reserved. Manufactured for and on behalf of the Environmental & Energy Solutions Division of Honeywell Technologies Sàrl, Z.A. La Pièce, 16, 1180 Rolle, Switzerland by its Authorized Representative, Trend Control Systems Limited.

Trend Control Systems Limited reserves the right to revise this publication from time to time and make changes to the content hereof without obligation to notify any person of such revisions or changes.

**Trend Control Systems Limited**

St. Marks Court, North Street, Horsham, West Sussex, RH12 1BW, UK. Tel: +44 (0)1403 211888, [www.trendcontrols.com](http://www.trendcontrols.com)