

D Montageanweisung
 F Instructions d'installation
 I Istruzioni di montaggio
 NL Installatievoorschrift
 DK Installasjonsinstruktus
 N Installationsinstruktioner
 FIN Asennusohje
 S Installation instruktioner
 E Instrucciones de montaje

43191680-005 Auxiliary Switches

INSTALLATION INSTRUCTIONS

00A

00B

- ML6420A3007
- ML6420A3015
- ML6420A3023
- ML6420A3031
- ML6420A3072
- ML6425A3006
- ML6425A3014
- ML6425B3005
- ML6425B3021

1

2

3

4

Manufactured for and on behalf of the Environmental & Energy Solutions Division of Honeywell Technologies Sàrl, Rolle, Z.A. La Pièce 16, Switzerland by its Authorized Representative:

Automation and Control Solutions

Honeywell GmbH
Böblinger Strasse 17
71101 Schönaich, Germany
Phone +49 (0) 7031 637 01
Fax +49 (0) 7031 637 740
<http://ecc.emea.honeywell.com>

MU1B-0348GE51 R1215B

Subject to change without notice